

Guardcote PolyPro Primer

Mixing and Application Instructions

For more in-depth instructions, review [Instructions for Painting Concrete and Metal](#) on our website.

- 1) Apply one coat to the substrate to which adhesion is desired. In some cases, both substrates should be coated in cases where there is metal to plastic bonding or plastic to plastic. Allow at least 24 hours' cure time at ambient temperatures prior to adhesion testing.
- 2) PRECAUTIONS: Warning: May cause irritation. Avoid contact with eyes and skin. In case of contact, flush eyes with plenty of water for at least 15 minutes. Seek prompt medical attention. Flush skin with water. Harmful if swallowed. If swallowed, drink large quantities of water. Call a physician. For industrial and institutional use only.
- 3) GUARANTEE: AMI guarantees its products, when used as directed, to do all it claims. Should the product fail to demonstrate our claims, the remaining material may be returned to us and no charge will be made.

ALWAYS! If you have a question concerning any phase of the application process, please call, and one of our techs will be happy to assist you.

ALWAYS! Remove any tool that might create an electrical spark during application. No lighters, cigarettes or flames of any kind are allowed anywhere near the application area.